



Confined Space Control Covers

★ Lockable Ratchet Strap Column/Skirt Covers Installation Instructions ★

*PLEASE READ AND FOLLOW ALL INFORMATION AND INSTRUCTIONS. FAILURE TO FOLLOW INSTRUCTIONS CAN RESULT IN IMPROPER USE AND PROTECTION OF YOUR CONFINED SPACE.

*COVERS ARE DESIGNED FOR LONG-TERM USE AND TO WITHSTAND CONSTANT EXPOSURE TO THE ELEMENTS.

BEFORE INITIAL USE: Inspect product for defects. If defects are present, contact CSCC Incorporated immediately for replacement. DO NOT USE if defective.

TIPS & TRICKS: Covers can be installed quickest with two people.

Do you have multiple opening around the same column? Quickly and easily hang as many covers as you need on the same straps to secure them all at the same time!

Locking is recommended but not required. This cover gives you the option to install a padlock, carlock, or simply tighten ratchet strap & leave as is.

HOW TO INSTALL

1 Unfold cover and inspect to ensure that you have your correct cover size and two ratchets with strapping attached.



2 Feed straps through cover holes on top & bottom of cover. If multiple openings are present, add additional covers onto straps.



3 Have someone assist you by holding the top ratchet and top of cover in position over the opening while you walk & stretch the strap around the skirt. When you meet back up with the top ratchet that is being held into position, feed the end of the strap through the ratchet to secure.



4 If needing to install padlock, it is best for you to run your lock through the first grommet, then crank the ratchet tight.



5 Insert padlock through grommet on handle and lock.



6 Repeat steps to secure bottom strap as well.



HELPFUL TIPS & INFO:

See images...

If the column/skirt has a transition which restricts your cover from making contact with the entire surface area, feel free to cut additional 2" vertical slits anywhere within the solid material on the sides of the cover so that you are able to tie additional rope/wire/cord/etc where needed to ensure the best fit.



CLEANING AND STORAGE: May be cleaned with mild soap & water. DO NOT scrub with harsh or abrasive material /solvents. Rinse thoroughly then lay flat. Allow to dry completely. Once dry, roll or fold cover, stack/store in a secure location. Do not store in closed container unless completely dry and free of moisture. Wash hands thoroughly after handling.

For helpful videos, information on all our cover designs, visit us online at www.ConfinedSpaceControlCovers.com or www.CSCCincorporated.com

281-332-1511
info@cscincorporated.com