



Confined Space Control Covers

★ Handling/Installation Instructions for Lockable Covers ★

*PLEASE READ AND FOLLOW ALL INFORMATION AND INSTRUCTIONS. FAILURE TO FOLLOW INSTRUCTIONS CAN RESULT IN IMPROPER USE AND PROTECTION OF YOUR CONFINED SPACE.

*FABRIC MAY BE STIFF WHEN NEW, BUT WILL BREAK IN AFTER SEVERAL USES.

*FABRIC IS MANUFACTURED USING A SPECIAL REINFORCED TECHNIQUE, MAKING THEM RESISTANT TO TEARING/RIPPING. EVEN WITH ABRASION, WEAR AND PUNCTURES, CONFINED SPACE CONTROL COVERS SHOULD OFFER THE SAME LEVEL OF PROTECTION AS WHEN NEW.

BEFORE INITIAL USE: Inspect product for defects. If defects are present, contact CSCC Incorporated immediately for replacement. DO NOT USE if defective.

HOW TO INSTALL

1 Locate strap ends at sleeve opening. Grabbing both ends, push fabric down.



2 Work fabric creases around cover to gather fabric and expose strap.



3 Feed gathered fabric around the cover, creating a pocket.



4 Place pocket over edge of flange. Work cover evenly around entire man-way.



5 Position cover evenly, making sure signage is straight. Pull both straps to wrap cover around back of flange.



6 Cross straps and pull tightly to secure cover and expose grommets.



7 Join two grommets closest to back of flange. Apply padlock.



Ventilated cover styles also available.



CLEANING AND STORAGE: May be cleaned with mild soap & water. DO NOT scrub with harsh or abrasive material /solvents. Rinse thoroughly then lay flat. Allow to dry completely. Once dry, roll or fold cover, stack/store in a secure location. Do not store in closed container unless completely dry and free of moisture. Wash hands thoroughly after handling.

For helpful videos, information on all our cover designs, visit us online at www.ConfinedSpaceControlCovers.com or www.CSCCincorporated.com

281-332-1511
info@cscincorporated.com